

Instructions for Fitting Kit Installation

- Remove top of trough
- Install Uniseal rubber gasket into a hole 1" larger than the drain pipe to be installed
- Put lubricant (or liquid soap) on Uniseal
- Insert the all-thread into the smaller part of the tool
- Place the larger U-shaped part of the tool inside the trough centered over the hole
- Position the pipe provided over the outside of the hole and run the all-thread through it and into the larger part of the tool inside the trough
- Tighten the nuts until the pipe is firmly in place in the gasket

